

User Manual

Make your life with cars more convenient



Audew

Please read the manual carefully before use and keep it for reference later

HOW TO USE:

- 1.Connect the compressor with the yellow air pipe.
- 2.Start the engine then insert in the 12V car cigarette lighter.
- 3.Connect the tire with the air pipe.
- 4.Turn it on and pay attention to the tire pressure table.
- 5.Turn it off when the tire reach the pressure you want.
- 6.Keep it in the dry place for the next use.

ATTENTION:

- 1.It can not be use for large truck.
- 2.Only for 12V car.
- 3.Do not leave it alone when it is working,and pay attention to the tire pressure.
- 4.Please star the car before turning on the air compressor.
- 5.The metal part may heat up after a long time use. So do not touch that part.
- 6.Do not use it for a long time,The product working time should not exceed 10 minutes,and should be turned off for a while before using again.
- 7.Please check the fuse when it can not work.
- 8.We recommend you use the alligator clamp,it would be safer for the fuse of your car. In addition,you also should start your car before using.
- 9.Please check the fuse when it can not work.